

RO'VED FIRMWARE v1.1 CHEATSHEET:

NAVIGATION BETWEEN SYNTHESIS MODELS:

- Press **FREQ** to move to the previous green model
- Press **TIMBRE** to move to the next green model
- Press **MORPH** to move to the previous red model
- Press **HARM** to move to the next red model



PUSH & TURN TO CHANGE ALTERNATIVE PARAMETERS:

- Push & Turn **TIMBRE** to change LPG / VCA
- Push & Turn **MORPH** to change internal envelope Decay
- Push & Turn **HARM** to change Frequency range



FREQUENCY LOCK:

- To toggle frequency lock press **TIMBRE & MORPH** simultaneously

FIRMWARE SETTINGS MENU:

- To enter or exit the menu press **FREQ & TIMBRE** simultaneously

MENU NAVIGATION:

- Press **FREQ** or **TIMBRE** to navigate between menu options
- Press **MORPH** or **HARM** to change the value

